

APPLICATION GUIDELINE - ROMEX® PROFI-DEKO (LARGE APPLICATIONS)

CAUTION: When using ROMEX® Profi-DEKO, it is important to ensure that the loose stones are clean and dry. All contents of the packaging should be used for best results.



1 Pour the clean and dry grit/gravel into the pug mill mixer or concrete mixer and start the mixing process.



2 Whilst mixing, slowly add the separately packaged 3 kg resin/hardener component completely into the mixture. Total mixing time: at least 6 minutes.



3 Pour the mix onto the prepared surface (minimum depth of 30mm); if necessary, disperse it with a shovel and ensure the desired depth is achieved.



4 Compact the mixture using a light vibratory plate or smoothing trowel and then smooth off the surface. Good compacting is essential for a durable end product! Allow to dry for 24hrs.

PLEASE NOTE: Do not leave material on the pavers to dry, as this will potentially cause hazing. ROMEX might temporarily stain the pavers, however, it is guaranteed to disappear after 4-12 weeks.
For more information - info@romex.co.za | 010 109 8520 | 071 681 9610

ROMEX®