

APPLICATION GUIDELINE - ROMEX® PROFI-DEKO (SMALL APPLICATIONS)

CAUTION: When using ROMEX® Profi-DEKO, it is important to ensure that the loose stones are clean and dry. All contents of the packaging should be used for best results.

- 1** Prepare surface for hardening by making sure it is compact and stable to a depth of at least 30 mm. Adjoining surfaces that are not to be joint-fixed must be taped off.
- 2** Thoroughly wash and clean the stones/gravel so that all dirt and debris are removed.
- 3** Allow the stones/gravel to dry out. We recommend placing them on a plastic sheet in direct sunlight.
- 4** Place the stones/gravel into a large bucket and add the required amount of resin. One 3kg unit treats approximately 120kg of stone/gravel (9-11mm).
- 5** Mix vigorously for at least 6 minutes.
- 6** Pour the mix onto the prepared surface; if necessary, disperse it with a shovel and ensure desired depth is achieved.
- 7** Compact the mixture using a trowel and then smooth off the surface. Good compacting is essential for a durable end product!
- 8** Allow to dry for 24 hours and make sure that there is no rain during this period.

PLEASE NOTE: Do not leave material on the pavers to dry, as this will potentially cause hazing. ROMEX might temporarily stain the pavers, however, it is guaranteed to disappear after 4-12 weeks.
For more information - info@romex.co.za | 010 109 8520 | 071 681 9610

